

University of Pittsburgh Safety Manual	EHS Policy #	05-004
Subject: BIOLOGICAL SAFETY CABINETS	Effective Date	Page 1 of 4
	1/1/07	

BIOLOGICAL SAFETY CABINETS

Properly maintained and utilized biological safety cabinets (BSC) provide effective containment for the safe manipulation of potentially infectious agents and provide a sterile work environment for the protection of experimental material. High Efficiency Particulate Air (HEPA) filters are installed on the exhaust plenum of BSCs to protect the environment and the worker. HEPA filtering of the supply air within the BSC protects the research materials from room contaminants.

1. Only biological safety cabinets listed in the latest edition of the *National Sanitation Foundation (NSF) Standard 49* (Class II Laminar Flow Biohazard Cabinetry) shall be purchased. EH&S is available to consult on BSC selection and location.
2. Biosafety Cabinet Terminology
 - 2.1 Class I BSCs are no longer manufactured on a regular basis. Usage of existing Class I BSCs should be limited to low risk biological agents in which protection of experimental material is not necessary.
 - 2.2 A Class II BSC is a front-opening cabinet with inward air flow to protect personnel, HEPA-filtered vertical laminar air flow to protect the work, and HEPA-filtered exhaust for environmental protection. Class II BSCs are divided into Types A or B.
 - 2.2.1 Class II Type A1 cabinets (formerly designated as Type A) utilize a design in which 70% of the cabinet air is recirculated to the cabinet work area through a HEPA filter; and the balance of the air can be exhausted through a HEPA filter back into the room or to the outside via a canopy exhaust connection.
 - 2.2.2 Class II, Type A2 cabinets (formerly designated as Type B3) function the same as Class II Type A1, except all biologically contaminated ducts and plenums under negative pressure are surrounded by negative pressure ducts and plenums.
 - 2.3 Class II Type B1 cabinets function in a manner in which 30% of the cabinet air is recirculated to the cabinet work area through a HEPA filter. The 70% balance of the air is exhausted through a dedicated duct to the atmosphere after passing through a HEPA filter.
 - 2.4 Class II Type B2 cabinets have HEPA filtered downflow air drawn from the laboratory, and exhaust 100% of the inflow and downflow air to the atmosphere after filtration through a HEPA filter. There is no recirculation of air in the cabinet or air returned to the laboratory
 - 2.5 Class III biological safety cabinets are totally enclosed with leak-tight construction. Operations in the cabinet are conducted through durable gloves attached to the cabinet, hence the term glove box. The cabinet is maintained under negative air pressure. Downflow air is drawn into the cabinet through HEPA filters. The exhaust air is treated by HEPA filtration. Class III BSCs are not recommended or necessary for most biomedical research that involves BSL 2 materials.

University of Pittsburgh Safety Manual	EHS Policy #	05-004
Subject: BIOLOGICAL SAFETY CABINETS	Effective Date	Page 2 of 4
	1/1/07	

3. Biosafety Cabinet Selection

- 3.1 Where biosafety cabinet applications will consist primarily of microbiological work and only minute or trace amounts of volatile hazardous chemicals will be utilized, a Type A2 cabinet with an exhaust canopy for discharge into the building exhaust system is recommended.
- 3.2 It is permissible under the 2002 NSF 49/ANSI Guidelines to exhaust Type A2 cabinets back into the laboratory provided that NO volatile or toxic chemicals and/or radionuclides are utilized in the BSC.
- 3.3 Where BSC applications could include work with more than minute quantities of volatile chemicals, or work with chemicals for which the physical properties or hazards are unknown or are known to present special hazards, a Type B2 cabinet is recommended. These cabinets provide 100% exhaust with no recirculation into the room or BSC. Exhaust from Type B2 cabinets must be interlocked with the blower or building exhaust system to prevent pressurization of the BSC.
- 3.4 If the primary use of the BSC will be to contain volatile or hazardous chemicals, and protection of the research product is not required, a chemical fume hood should be considered. For applications that require product protection, such as transgenic animal or *in vitro* work, a chemical fume hood with not offer the necessary product protection.
4. All biological safety cabinets shall be certified annually per the testing specifications found in NSF 49 and the manufacturer's specification.
5. All new BSCs shall be certified following installation, and before initial use.
6. All Type A2 biological safety cabinets in BSL-3 facilities must be installed with a thimble/canopy connected to the exhaust air system.
7. Performance tests/certifications are to be conducted by a NSF-certified contractor experienced in BSC testing. Arrangements for performance testing and certifications are initiated by the Investigator or department owning the equipment.
8. Before disassembling or moving a biological safety cabinet, appropriate decontamination by an experienced contractor is required. Relocated BSCs shall be re-certified following re-installation, but before resuming use.
9. When maintenance work, filter changes, and performance tests require access to the sealed, potentially contaminated portion of the cabinet, appropriate decontamination of the entire BSC is required.
10. All BSCs must be clearly labeled with the class and type, the date of the last certification, the name of the person performing the test, and the company name.

University of Pittsburgh Safety Manual	EHS Policy #	05-004
Subject: BIOLOGICAL SAFETY CABINETS	Effective Date	Page 3 of 4
	1/1/07	

11. Use of Gas Burners or Open Flames in Biosafety Cabinets

11.1 The use of gas burners in biosafety cabinets has led to fires, destroyed cabinets, and injured workers. **It is not recommended to use gas burners or open flames in biosafety cabinets. This recommendation is supported by the CDC.**

11.1.1 Depending on the type of BSC, a certain percentage of air is recirculated inside the BSC. If gas leaks out of a gas valve, it can accumulate inside the cabinet and ignite when the flame is lit.

11.1.2 Excess latex tubing can loop over the flame and be burned, causing a flame to shoot out of the gas valve.

11.2 The use of gas burners or open flames will compromise the function of the biosafety cabinet. The biosafety cabinet provides worker protection by drawing air into the cabinet and filtering microorganisms out through a HEPA filter. The heat produced from a gas burner can disrupt the fragile air barrier inside the biosafety cabinet and expose workers to air from inside the cabinet; and the heat can disrupt normal exhaust flows.

11.3 Eliminate use of gas burners within BSCs. Use only sterile disposable plastic ware instead of glassware that must be flamed. Rely upon good chemical disinfection, such as bleach or other commercial disinfectants, to clean equipment and surfaces. Use an electric device such as a Bacti-cinerator for high heat applications.

11.4 Use proper work practices to maintain a sterile environment inside to cabinet to eliminate the need for flame sterilization.

- Minimize movement in and out of the biosafety cabinet.
- Place all working materials inside the biosafety cabinet before beginning work. This will help preserve the air barrier in the front of the biosafety cabinet.
- Work from clean to dirty, by placing all contaminated materials on one side of the biosafety cabinet.
- Collect all wastes such as contaminated plastic ware in a bag in the biosafety cabinet and then dispose it in a larger biohazard bag outside of the cabinet when work is completed.

11.5 If a gas burner must be used, then a touch-plate gas burner should be substituted for a Bunsen burner.

- Once the pilot light is lit, it remains small, and the worker must touch a metal plate to increase the flame.
- Keep lengths of tubing as short as possible to avoid looping and burning through the tubing.
- Use butyl rubber tubing instead of latex tubing and inspect regularly.
- **Do not leave gas burners unattended.**

University of Pittsburgh Safety Manual	EHS Policy #	05-004
Subject: BIOLOGICAL SAFETY CABINETS	Effective Date	Page 4 of 4
	1/1/07	

For more information on the performance, use, and certification of BSCs refer to the following references:

- National Sanitation Foundation Standard No. 49, Class II (Laminar Flow) Biohazard Cabinetry, (2002). Ann Arbor, MI.
- Biosafety in Microbiology and Biomedical Laboratories, US Dept. of Health and Human Services Publication No. CDC 93-8395, 4th Edition (1999). Center for Disease Control, Atlanta, GA.
- Primary Containment for Biohazards: Selection, Installation, and Use of Biological Safety Cabinets, 2nd ed., US Department of Health and Human Services, 2000.